


1. Visualizing sample Images



2. Pixel Intensity Analysis

1. Differentiating Between Defective and Non-Defective Areas

Pixel intensities vary between powder, printed, and defective regions.

Helps in setting thresholds to classify different defect types.

2. Identifying Defect Severity

Higher intensities (closer to white, 255) → Over-melting or recoater issues.


Lower intensities (closer to black, 0) → Under-melting, debris, or incomplete spread

The intensity variance gives clues about defect severity.

3. Detecting Changes Across Layers (Before & After Melting)

Helps in analyzing powder distribution consistency before melting.

Detects how defects evolve after melting.



3. Defect Area Distribution Analysis

This analysis helps in understanding the **nature and severity** of defects in additive Manufacturing.


Defect Area Distribution (Before Melting):

```
{'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class2': 0,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class3':
3965232,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class4':
1175512,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class6': 0,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class7':
10}
```

Defect Area Distribution (After Melting):

```
{'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class5':
3021601,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class8':
110397626,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class9':
8124,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class10':
0,
'/content/drive/MyDrive/Info_Project/Defect_Detection/DataSets/Processed_Data/Defect_Class11':
0}
```

Execution Time: 36 min




4. Defect Location Heatmaps

Overlay defect masks onto the original images to visualize common defect regions.


Create a heatmap showing defect density across all images.

Execution time: 29 min

Defect Location Heatmap (Before Melting)



Defect Location Heatmap (After Melting)



5. Defect Class Frequency Analysis

This Analysis helps determine how often each defect type occurs in the dataset.

- **Understanding Manufacturing Issues**

- >> Frequent defects can indicate underlying process issues in additive manufacturing
- >> Certain defects (e.g., recoater streaking(3), Incomplete Spreading(4)) occur more than others, it could point to equipment malfunctions.

- **Setting Priorities for Quality Control**

- >> Some defects are very rare; they may not be a major concern in quality inspection.
Ex. Over Melting(10), Under Melting(11), Recoater Hopping(2), Debris(6),
Super-Elevation(7)
- >> Helps decide **which defects require immediate attention** in real-world Applications.
Ex. Swelling(5), Spatter(8), Misprint(9), Recoater Streaking(3),
Incomplete Spreading(4)

After Melting Defect Class:

```
{'Defect_Class5': 3573,  
'Defect_Class8': 3573,  
'Defect_Class9': 119,  
'Defect_Class10': 0,  
'Defect_Class11': 0}
```

Powder Bed (Before Melting) Defect Class:

```
{'Defect_Class2': 0,  
'Defect_Class3': 819,  
'Defect_Class4': 67,  
'Defect_Class6': 0,  
'Defect_Class7': 1}
```

Execution Time: 17 min

